



PRESSURE/TORQUE CONVERSION CHART

8HP

PRESSURE IN PSI	FT. LBS.	N-m
1500	1037	1406
1600	1110	1505
1800	1257	1704
2000	1403	1902
2200	1547	2097
2400	1690	2291
2600	1833	2485
2800	1977	2680
3000	2120	2874
3200	2265	3071
3400	2410	3267
3600	2555	3464
3800	2700	3661
4000	2852	3867
4200	2991	4055
4400	3137	4253
4600	3284	4452
4800	3430	4650
5000	3576	4848
5200	3723	5048
5400	3870	5247
5600	4018	5448
5800	4165	5647
6000	4312	5846
6200	4465	6054
6400	4619	6262
6600	4773	6471
6800	4926	6679
7000	5080	6887
7200	5223	7081
7400	5367	7277
7600	5510	7470
7800	5654	7666
8000	5723	7759
8200	5954	8072
8400	6111	8285
8600	6267	8497
8800	6424	8710
9000	6581	8923
9200	6730	9125
9400	6880	9328
9600	7029	9530
9800	7178	9732
10000	7320	9924

