



PRESSURE/TORQUE CONVERSION CHART

1IBT

PRESSURE IN PSI	FT. LBS.	N-m
1500	176	239
1600	185	251
1800	205	278
2000	225	305
2200	250	339
2400	275	373
2600	300	407
2800	330	447
3000	350	475
3200	385	522
3400	410	556
3600	438	594
3800	465	630
4000	498	675
4200	518	702
4400	542	735
4600	568	770
4800	597	809
5000	618	838
5200	641	869
5400	668	906
5600	698	946
5800	726	984
6000	749	1015
6200	776	1052
6400	796	1079
6600	832	1128
6800	866	1174
7000	891	1208
7200	923	1251
7400	951	1289
7600	983	1333
7800	1016	1377
8000	1029	1395
8200	1053	1428
8400	1079	1463
8600	1105	1498
8800	1130	1532
9000	1155	1566
9200	1179	1598
9400	1204	1632
9600	1231	1669
9800	1256	1703
10000	1282	1738

