

PRESSURE/TORQUE CONVERSION CHART

PRESSURE IN PSI	FT. LBS.	N-m	.7MD
1000	64	86	
1200	79	108	
1400	95	128	
1600	110	149	
1800	126	171	
2000	140	190	
2200	156	212	
2400	172	233	
2600	189	256	
2800	205	277	
3000	221	299	
3200	237	321	
3400	253	343	
3600	270	366	
3800	287	389	
4000	302	410	
4200	319	433	
4400	335	454	
4600	352	477	
4800	368	498	
5000	384	521	
5200	401	543	
5400	417	565	
5600	434	588	
5800	450	610	
6000	466	632	
6200	483	654	
6400	499	676	
6600	515	699	
6800	531	720	
7000	548	743	
7200	564	765	
7400	581	787	
7600	598	811	
7800	614	832	
8000	631	856	
8200	647	877	
8400	664	900	
8600	679	921	
8800	695	943	
9000	711	964	
9200	728	987	
9400	745	1010	
9600	761	1031	
9800	778	1054	
10000	793	1076	

