



PRESSURE/TORQUE CONVERSION CHART

4HP

PRESSURE (PSI)	FT. LBS.	NM
1000	439	595
1200	530	719
1400	617	837
1600	707	959
1800	796	1079
2000	882	1196
2200	976	1323
2400	1055	1430
2600	1150	1559
2800	1240	1681
3000	1332	1806
3200	1423	1929
3400	1513	2051
3600	1606	2177
3800	1694	2297
4000	1786	2421
4200	1880	2549
4400	1972	2674
4600	2060	2793
4800	2152	2918
5000	2243	3041
5200	2334	3164
5400	2425	3288
5600	2518	3414
5800	2607	3535
6000	2697	3657
6200	2790	3783
6400	2882	3907
6600	2972	4029
6800	3065	4156
7000	3154	4276
7200	3246	4401
7400	3337	4524
7600	3430	4650
7800	3521	4774
8000	3614	4900
8200	3703	5021
8400	3791	5140
8600	3880	5261
8800	3972	5385
9000	4067	5514
9200	4155	5633
9400	4253	5766
9600	4343	5888
9800	4429	6005
10000	4500	6101